
Turning on the TV

- 1. Press the **ON** button on the Extron control panel, located on the top of the equipment rack.
- 2. Wait a moment for the TV to warm up.



How to Project using HDMI

- 1. Make sure the TV is turned on (see instructions above).
- 2. Make sure your computer is turned all the way on and that you're logged in.
- 3. Plug the HDMI cable into the HDMI port on your machine.
 - If you need to use an adapter, plug the HDMI cable first into your adapter, and then plug the adapter into your computer.
- 4. If your laptop does not automatically duplicate your screen and the image from the TV: On
 - Windows computers, press your Windows key and your P key at the same time. Select Duplicate to send the image to the TV.
 - On a Mac, navigate to Apple menu (€) > System Preferences > Displays > Arrangement tab > check Mirror Displays.
- 5. If your computer doesn't switch its audio output to HDMI automatically:
 - On Windows computers, right-click on the speaker icon in your notification bar, and select Playback devices in the resulting pop-up menu. Right-click on the HDMI output device, and select Set as Default in the resulting pop-up menu.
 - On a Mac, navigate to Apple menu (*) > System Preferences > Sound > Output tab >
 Select the device with Extron in the name.
- 6. **Turn off the TV when you're done using it!** Press the **Off** button on the Extron control panel to turn off the TV.

How to Project using VGA

- 1. Make sure the TV is turned on (see instructions above).
- 2. Make sure your computer is turned all the way on and that you're logged in.
- 3. Plug the VGA cable into the VGA port on your machine.
 - If you need to use an adapter, plug the VGA cable first into your adapter, and then plug the adapter into your computer.

- 4. If your laptop does not automatically duplicate your screen and the image from the TVs: On
 - Windows computers, press your Windows key and your P key at the same time. Select Duplicate to send the image to the TV.
 - On a Mac, navigate to Apple menu (€) > System Preferences > Displays > Arrangement tab > check Mirror Displays.
- 5. Volume is controlled **first** by your computer's output volume and **then** by the room's sound system. Turn your computer's volume all the way up before adjusting the room's sound system's volume.
- 6. **Turn off the TV when you're done using it!** Press the **Off** button on the Extron control panel to turn off the TV.

How to Project using the iMac

- 1. Make sure the TV is turned on (see instructions above).
- 2. Make sure the Mac Mini is turned all the way on and that you're logged in. If the Mac Mini is not powered on, reach around the left rear corner of the computer and press the power switch.
- 3. Select the MAC input on the Extron Controller.
- If the Mac Mini does not automatically duplicate to the TV screen, navigate to
 Apple menu (> System Preferences > Displays > Arrangement tab > check Mirror Displays.
- 5. Turn off the TV when you're done using it!

How to Project using the Blu-ray Player

Note: Blu-ray players play Blu-ray disks, DVDs, and CDs.

- 1. Make sure the TV is turned on (see instructions above).
- 2. Press the **Blu-ray** button on the Extron control panel.
- 3. Press the **Eject** button on the face of the Blu-ray player on the front of the equipment rack. The Blu-ray player is the only rack mounted unit with a screen on it. The **Eject** button is located to the left of the screen and the right of the disk tray.
- 4. Put your Blu-ray, DVD, or CD on the tray, and then use the **Eject** button to close the tray. **Don't** push the tray closed manually!
- 5. Your disk will automatically start playing.
- 6. Control playback using the arrow and menu buttons on the Extron control panel.
- 7. Don't leave your disk in the player when you're done! Be sure to retrieve your disk before you leave.
- 8. **Turn off the TV when you're done using it!** Press the **Off** button on the Extron control panel to turn off the TV.

For help with classroom technology, please email help@help.carthage.edu or call the helpdesk at (262) 551-5950.

Experiencing an issue? Restart the System

- 1. Shut off what you can by going to **Power Control > Shut Down System**.
- 2. Follow the bundle of cables running from the equipment rack to the wall.
- 3. From that bundle of cables, identify the power cable plugged into the power outlets in the wall. Unplug it from the wall.
- 4. Count to 20 seconds.
- 5. Plug the power cable back into the wall.
- 6. Wait for the touch panel to finish starting up, then try projecting again.

Leaving the TV running for extended periods while it's not in use significantly shortens the life of the TV. Please turn off the TV when you're done using it!

Jan. 2022